


JADCO FASTENER INSTALLATION

A favorite among memorialists for generations, the Jadco™ fastener is a quick, easy and inexpensive method for securely fastening your Dedo Classic™.

How to install a Dedo Classic using the Jadco fastener

1. Trace outline of portrait on monument;
2. Drill hole $3/8$ " wide and $3/4$ " deep at $7/8$ " above center on vertical or $7/8$ " to left of center on horizontal portraits (figure A);
3. Place fastener in hole and expand with pellets;
4. Slide portrait upward (for vertical) or to the left (for horizontal) with your palm until tang locks in position as per figure B.

We also offer a threaded Jadco(tm) ($5/16$ " wide by 2" long for bolt-through applications).



HORIZONTAL




Fig. A




Fig. B

How to remove a Dedo Classic using the Jadco fastener

For removal from Jadco(tm) fastener, slide a hacksaw halway up behind the center of the portrait. Do not lift the portrait more than the thickness of the blade. A click will indicate that the tang has been depressed, at which point you may lower the portrait (please see figure C).




Fig. C